

Due to the limitations of the internet and different display colours should only be considered as an indication.

Essences



ES406
Moka tainted oak-tree



ES511
Ebony



ES521
Teak

Varnished




LA001
Bright white



LA002
Bright black




LA003
Bright red



LA101
Mat white



LA102
Mat black



LA201
Antiscratch white



LA202
Antiscratch black

Maintenance and cleaning of wooden parts

The cleaning. We recommend that you clean these parts rubbing with a soft cloth in the sense of veins, using alcohol diluted with water and drying immediately with a soft and dried cloth. When the dirt is difficult, such as crayon stains or similar, we recommend to use denatured alcohol.

To avoid. SWe do not recommend the use of wax for polishing furniture because they may contain solvents or dyes not suitable for the cleaning of your furniture.

Attention. The differential exposure to light can lead over the years, slight variations of color. Please avoid exposure to direct sunlight.